


EPD36 Electromagnetic Flow Meter -Quick Start Guide-



01 Take Note Before Use

This guide provides basic information to help you get started. Please visit the website to download the full user manual for detailed installation and additional information. Incorrect operation may result in fatal or serious hazards.

Explosion hazard – If maintenance is required, the device must be removed from the hazardous area. To prevent ignition of flammable or combustible gases, disconnect the power supply before servicing.

Ensure that the installation of the equipment complies with the applicable national electrical code requirements. Installation of the equipment should only be performed by qualified personnel or factory representatives.



Note:


All junction box gaps must be completely sealed using sealing tape or sealant. Failure to seal all gaps may allow moisture to enter the equipment, potentially damaging internal components and voiding the warranty.

02 Product Specifications

100~240Vac 50/60Hz or 24Vdc
4-20mA / Pulse:NPN 32Vdc /200mA

03 Grounding

The sensor and transmitter should be equipped with high-quality independent grounding wire (The section area of the copper core is 1.6mm²). The grounding resistance should be <10Ω. If the grounding is poor, it won't work normally. The grounding ring is needed if the pipe connecting with the sensor is insulating, and the material of the grounding ring should be the same as that of the electrode.




The flow meter is installed on a metal pipe, where the inner wall of the metal pipe has no insulating coating.

04 Installation

All enclosure covers must be securely fastened to prevent the influence of external environmental factors.

Minimum upstream/downstream pipeline requirements:

- A: Upstream – 5 times the pipe diameter
- B: Downstream – 2 times the pipe diameter
- C: Flow direction



<p>Correct method: Sensor to transmitter (arrows on the LCD and sensor should point in the same direction)</p>	<p>Incorrect orientation: Sensor to transmitter (The arrows on the LCD and sensor are not pointing in the same direction)</p>
---	--




Do not change the orientation of the transmitter display on the sensor line. The blue arrows on the LCD screen and the sensor must point in the same direction. Rotating the transmitter orientation on the sensor tube may damage the transmitter's wiring harness and internal circuitry, and void the warranty.


05 Wiring

The wiring terminals can be seen after opening the outer cover.

- ▶ 4-20mA: MA-(P9) / MA+(P11)
- ▶ Digital input: DI+(P13) / DI-(P14)
- ▶ Digital output 1: DO1-(P10) / DO1+(P12)
- ▶ Pulse output: P-(P5) / P+(P7)
- ▶ RS485: D-(P1) / D+(P3)





06 Display Interface / Button Functions




- ① Instantaneous flow rate
- ② Volume accumulation
- ③ Pressure in Tube
- ④ Percentage of measuring range
- ⑤ Number plus button
- ⑥ Left button/Return to the previous page
- ⑦ Confirm button (keep pressing)

07 Preset LCD screen




By default, the LED display will switch between the main measurement screen and the empty tube alarm screen.

08 LED Menu System




Press the ENT button until the operation screen appears.




Press the up key to navigate to either "Cancel" or "Accept". Press the ENT button



Press the up button to move to the selected item in the menu. Press the ENT button



Press the up button to move to the selected item in the menu. Press the ENT button



Use the up and left buttons to adjust the value. Press the ENT button to save.